


Also available as non-overflowing model Adam-NO.
 Please follow all local plumbing codes to prepare your bathroom floor for the installation of a non-overflowing bathtub. Specifically - ensure that a floor drain is installed and a proper floor sloping towards the floor drain is observed to eliminate any risk of flooding.

DRAWN YURI TYMOCHKO	2016-11-09	 Olympian by Savio		
CHECKED				
QA		TITLE		
APPROVED				
		SIZE C	DWG NO	REV
		SCALE		SHEET 1 OF 1